






Ceiling mount bracket for DWC-PDS10Wi28A dual-sensor vandal dome cameras

DWC-DSCM



WHAT'S IN THE BOX


| | | | | | |
|---------------------------------|---|---|-------------------|---|---|
| Camera Mounting Screws (12.7mm) |  | 4 | Mounting Pad |  | 1 |
| Quick Setup Guide |  | 1 | Mounting Template |  | 1 |
| Screws and Plastic Anchors |  | 4 | | | 1 |

INSTALLATION


- 1 Using the mounting template or the mounting bracket itself, mark and drill the necessary holes on the mounting surface.
- 2 Secure the mounting bracket to the mounting surface using the screws and anchors included with the mount. Use the mounting pad between the bracket's arm and mounting surface as needed.
- 3 To mount the camera to the mounting accessory, remove the dome from the camera using the wrench included with the camera.

NOTE: Do not touch the lens when handling the camera.


- 4 Pass wires through and make all necessary connections.
- 5 Secure the camera to the mounting bracket using the included screws.
- 6 Adjust the camera's lens modules' position and angle and place the cover dome on the camera base to complete the installation.



Ceiling mount



Camera base



Camera dome cover

